

FILTER KITS CATALOGUE/ CATALOGO KIT FILTRI



WHEEL LOADERS

JADERPARTS SRL

13, Via Primo Maggio
40011 Anzola dell'Emilia (BO), Italy

<https://jaderparts.com/>

Contact us:

Phone: +39 051735493

E-mail: info@jaderparts.com

L60E

500 hours	FK500-0001	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-0001	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-0001	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1

L60F

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-9740	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-9741	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L60G

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-0002	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-0002	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L60H

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-0002	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-0002	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L70E

500 hours	FK500-0001	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-0001	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-0001	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1

L70F

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-9740	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-9741	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L70G

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-0002	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-0002	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L70H

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-0002	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-0002	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L90D

500 hours	FK500-6685	• Oil filter	<i>Filtro olio</i>	1
1000 hours	FK1000-6686	• Air filter	<i>Filtro aria</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	2
		• Water separator	<i>Separatore acqua</i>	1
2000 hours	FK2000-6687	• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab Filter	<i>Filtro cabina</i>	1
		• Filter cartridge	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	2
		• Water separator	<i>Separatore acqua</i>	1

L90F

500 hours	FK500-9739	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-9740	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-9741	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L110F

500 hours	FK500-9746	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-5197	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-5214	• Transmission filter	<i>Filtro trasmissione</i>	1
		• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L110G

500 hours	FK500-6591	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
1000 hours	FK1000-6594	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-6632	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Hydraulic Filter	<i>Filtro idraulico</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L110H

500 hours	FK500-6591	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
1000 hours	FK1000-6594	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-6632	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Hydraulic Filter	<i>Filtro idraulico</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L120C

500 hours	FK500-6668	• Oil filter	<i>Filtro olio</i>	1
		• Oil filter	<i>Filtro olio</i>	1
1000 hours	FK1000-6674	• Cabin Filter	<i>Filtro cabina</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Cab filter	<i>Filtro cabina primario</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Oil filter	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	2
		• Air filter	<i>Filtro aria</i>	1
2000 hours	FK2000-6677	• Cabin filter	<i>Filtro cabina</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Cab filter	<i>Filtro cabina primario</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	2
		• Air filter	<i>Filtro aria</i>	1
• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1		

L120E

500 hours	FK500-9746	• Water separator	<i>Separatore acqua</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
1000 hours	FK1000-5197	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
2000 hours	FK2000-5214	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	2
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1

L120F

500 hours	FK500-9746	• Oil filter	<i>Filtro olio</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Water separator	<i>Separatore acqua</i>	1
1000 hours	FK1000-5197	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-5214	• Transmission filter	<i>Filtro trasmissione</i>	1
		• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L120G

500 hours	FK500-6591	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
1000 hours	FK1000-6594	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-6632	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Hydraulic Filter	<i>Filtro idraulico</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L120H

500 hours	FK500-6591	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
1000 hours	FK1000-6594	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1
2000 hours	FK2000-6632	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	3
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Hydraulic Filter	<i>Filtro idraulico</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter	<i>Filtro olio</i>	1

L150E

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
• Oil filter	<i>Filtro olio</i>	2		
2000 hours	FK2000-6663	• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Air filter	<i>Filtro aria</i>	1
		• Ai filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab Filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Oil filter bybass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L150F

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L150G

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L150H

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L180F

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L180G

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L180H

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L220G

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L220H

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L250G

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L250H

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6657	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6655	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Cabin filter	<i>Filtro cabina</i>	1
		• Hydr. filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Hydraulic filter	<i>Filtro idraulico</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2

L350F

500 hours	FK500-6649	• Water separator	<i>Separatore acqua</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
1000 hours	FK1000-6594	• Air filter	<i>Filtro aria</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2
2000 hours	FK2000-6632	• Air filter	<i>Filtro aria</i>	1
		• Air filter safety	<i>Filtro aria sicurezza</i>	1
		• Water separator	<i>Separatore acqua</i>	1
		• Air filter (breather)	<i>Filtro sfiato</i>	4
		• Hydraulic filter	<i>Filtro idraulico</i>	2
		• Cab filter	<i>Filtro cabina</i>	1
		• Hydr. Filter (breather)	<i>Filtro idraulico sfiato</i>	1
		• Transmission filter	<i>Filtro trasmissione</i>	1
		• Primary cab filter	<i>Filtro cabina principale</i>	1
		• Fuel filter	<i>Filtro carburante</i>	1
		• Oil filter bypass	<i>Filtro olio bypass</i>	1
		• Oil filter	<i>Filtro olio</i>	2